MOTOR AND DRIVE PARTS

KitchenAid®

For Model: KUCC151GSS1
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	777971	Switch, Motor
2	9870343	Motor, Drive (Includes No. 1)
3	9871067	Screw, 1/4−20 x 3/4 (4)
4	776327	Plate, Drive Mount
5	776338	Locknut, 10−32 (4)
6	4149667	Gear, Drive
7	454512	Pin, Slotted Spring
8	776035	Washer, Wave
9	297462	Washer, Thrust
10	777124	Gear, Driven
11	776036	Clip, Ring
12	780477	Chain, Drive

Parts Not Illustrated and Optional Parts (Not Included)

9870118	Undercounter Conversion Kit

Following Parts Not Illustrated

LITERATURE PARTS

LIT9871512	Sheet, Tech
LIT9871628	Guide, Use & Care
LIT9744469	Label, 1−800 Number

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FRAME PARTS

For Model: KUCC151GSS1

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1		Frame (Not A Serviceable Part)
2	9870867	Shield, Slide Track (2)
3	9870976	Frame, Slide (R.H.)
	9870975	Frame, Slide (L.H.)
4	4153788	Bearing, Roller (2)
5	776356	Locknut, 3/8−24 (2)
6	777458	Screw, 6−32 x 3/8 (4)
7	4390387	Nut, 6−32 (4)
8	780437	Pan, Bottom
9	489478	Screw, 8 x 1/2
10	4149659	Shield, Harness
11	777070	Screw, 8−32 x 5/16
12	780434	Cover, Motor
13	608009	Plate, Motor Cover
14	776780	Barrier, Glass
15	4149377	Switch, Drawer Safety
16	775668	Anble, Top Support
18	777811	Switch, Top Limit & Directional
19	777849	Screw, 6−20 x 1" (2)
20	777850	Plate, Nut
21	9871540	Harness−Cord, Power
22	776119	Bushing, Cord
23	777035	Clamp, Wire
24	776118	Grommet, Motor Cover
25	775526	Leveler, Front (2)
27	9870585	Wheel, Leveler (2)
28	780034	Screw, 10−24 x 3/8 (2)
30	9870444	Panel, Inner
33	777180	Spring, Container

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

POWERSCREW AND RAM PARTS

For Model: KUCC151GSS1
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9870500	Screw, Power Complete Assembly (2)
2		Screw, Power (Available Only As Complete Assembly)
3	776942	Plate, Bearing (2)
4	775482	Bearing, Needle (2)
5	776941	Hub, Power Screw (2)
6	775481	Race, Thrust (2)
7	777385	Sprocket, Washer (2)
8	4154842	Nut, Power Screw (2)
9	777332	Washer, Cone (2)
10	9871067	Screw, 10−24 x 3/4 (4)
11	9871251	Ram Assembly
12	9870163	Nut, Power (2)
13	90296	Clip (4)
14	9870187	Stud (2)
16	9870037	Stop, Ram (2)
17	9870498	Bracket, Top Limit Switch
18	489399	Screw, (2)
19	9870775	Cap, Stop (2)
20	9870169	Slide, Ram (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTAINER PARTS

For Model: KUCC151GSS1
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	246131	Screw, Hex Head
2	9871564	Handle, Container (Includes Screws)
3	9871559	Panel, Container
4	9871563	Spacer, Handle (2)
5	9870996	Container Assembly
7	4149672	Pedal, Foot
8	780263	Screw, Shoulder #8−32 x 3/8 (2)
9	776395	Guide, Rear Latch
10	9870066	Latch Assembly
12	9871125	Spring, Safety Switch
13	775785	Bumper, Container (2)
15	489478	Screw, 8 x 1/2
16	9871602	Container, Bearing Roller
17	776356	Locknut, 3/8−24 (2)
18	777328	Plate, Toe Guard
20	776654	Pin
21	775736	Spring, Latch
22	775735	Ring, ‘‘E’’
23	775665	Plate, Latch
25	4147703	Retainer, Bag (Contains 4 Each)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PANEL AND CONTROL PARTS

For Model: KUCC151GSS1

(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
1	9871072	Panel, Front Frame
2	608572	Cover, Top
3		Bracket, Retainer
	9870157	R.H.
	9870158	L.H.
4	2005292	Nameplate
5	780239	Bracket, Retainer (Alternate) (2)
6	489478	Screw, 8 x 1/2AB (6)
7	9871560	Escutcheon, Control
8	246131	Screw, 6−20 x 3/8 (2)
9	4152703	Strap, Fan
10	608824	Switch, Rotary Start−Run
11	9871365	Knob, Rotary Switch
12	777383	Nut, Rotary Switch
13	4152058	Switch, Drawer
14	9871105	Switch, Rocker
15	4151442	Compartment, Air Freshener
16	780387	Bezel
17	780034	Screw, 10−24 x 3/8
18	9871104	Switch, Air Freshener
19	9871099	Cover, Air Freshener
20	4151750	Filter, Charcoal
21	2004333	Palnut (2)
23	9871051	Fan, Filter
24	4151897	Clip, Wire
25	4151897	S−Clip
26	780417	Bracket, Switch

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ACCESSORY PARTS

For Model: KUCC151GSS1
(Stainless Steel)



Illus. No.	Part No.	DESCRIPTION
		The Accessory Parts Listed Below May or May Not Be Included With Your Compactor.
1		Panel, Container Front
	9871309	White
	9871311	Black
	9871310	Almond
	9871312	Stainless Steel
2		Bag, Trash (15" Plastic)
	4318921	15 Pack
	4318922	60 Pack
	94318921	12 Boxes of 15 Pack

Illus. No.	Part No.	DESCRIPTION
3	777635	Deodorizer, Solid Stick−Ups (2−Pack)
5	13030	Carrier, Bag (Includes No. 6)
6	777108	Handle, Bag Carrier
7	675351	Grease, 4 Oz. (Use on Power Screw & Ram Pressure Pads
8		Wire, 25’ Roll
	10875	Blue 16 Ga.
	242820	Black 14 Ga.
	242825	Red 14 Ga.
	242826	White 14 Ga.
	47261	Black 12 Ga.
	299885	Red 12 Ga.
	47263	White 12 Ga.

Illus. No.	Part No.	DESCRIPTION
9	279368	Adhesive, Insulation (2oz Tube)
10		Paint, Touch−Up 1/2 Oz.
	72107	Almond
	72032	Black
	72110	Harvest Gold
	72113	Platinum
	72112	Toast
	72017	White
11		Paint, Spray 13 Oz.
	350956	Almond
	285006	Black
	261890	Harvest Gold
	285366	Platinum
	285365	Toast
	350930	White